

Cover Kit Installation Instructions



Separate the tubing and parts from front to back as the backs are installed first. Front tubing is smooth and smaller to ensure a secure fit. Be sure to keep screws with the applicable part.



Place the wall cover over the installation hole. Once it is properly aligned, secure the wall cover flush to the outer wall by fastening with screws into the predrilled holes.



Align evenly and place the back tubing slightly inside the wall cover. Drill one hole (not predrilled) in the center of the tube and fasten with a screw. Secure backs of the coupler and/or elbow (if included) by fastening with the applicable screws into the middle predrilled holes.



Carefully place and fasten your refrigerant, plumbing or any other necessary piping to fit along the inside of the backs of the now secured tubing.



First, snap tightly the front cover of tubing over the back cover. Then, snap the front covers of the other parts onto the backs for a smooth finished appearance. Using applicable screws, secure the front parts into the predrilled holes.



Place the end cap over the bottom and secure using applicable screws to fasten through the predrilled holes.